



Direct Mounting Installation

STEP 1



Install post in-ground to desired height. We recommend a minimum of 18" of post burial. Fill hole with roughly 20-25 pounds of "Quikcrete" cement.



STEP 2



Hardware & Tools:

- (2) Threaded Studs
- (2) Flat Washers
- (2) Acorn Nuts
- 7/16" Wrench
- Allen Wrench

STEP 3



Thread studs into back of sign and tighten with pliers. Be sure not to strip the threads when completing this process.

Post Bases & Finials

Install decorative options and secure with provided stainless steel setscrews before attaching sign to post. Be careful not to damage post finish during installation.

STEP 4



Place sign against post inserting studs through holes. Fasten sign to post with provided washers and acorn nuts using a 7/16" wrench.

STEP 5



Adjust sign before tightening bolts.