



Granite Tablet Yard Arm Installation

STEP 1



Install post in-ground to desired height. We recommend a minimum of 18" of post burial. Fill hole with roughly 30-35 pounds of "Quickcrete" cement.



STEP 2



Lift sign tablet into place. Slide vertical hanger arm brackets into the channels on the back of mounting tablet.

STEP 3



Secure tablet to the sign bracket with Allen wrench and provided set screws.

STEP 4



Adjust sign before tightening bolts.

Post Bases & Finials

Install decorative options and secure with provided stainless steel setscrews before attaching sign to post. Be careful not to damage post finish during installation.