



# Side Mounting Installation

## STEP 1



Install post in-ground to desired height. We recommend a minimum of 18" of post burial. Fill hole with roughly 20-25 pounds of "Quikcrete" cement.



## STEP 2



### Hardware & Tools:

- (2) Side Arm Brackets
- (4) Flat Washers
- (2) Acorn Nuts
- (2) 1/2" Machine Screws
- (2) Hex-Head Bolts
- 7/16" Wrench
- Allen Wrench



## STEP 3



Secure Side Arm Brackets to back of sign with the (2) 1/2" screws. Be sure to rotate brackets in the direction you wish your sign to hang in relation to the post (left or right).

## STEP 4



While holding sign against post, align holes in bracket with holes in post. Insert Hex-Head bolts using flat washers. Tighten sign brackets to post with provided acorn nuts and 7/16" wrench.

## STEP 5



Adjust sign before tightening bolts.

### Post Bases & Finials

Install decorative options and secure with provided stainless steel setscrews before attaching sign to post. Be careful not to damage post finish during installation.